

# WIDTH CHART

	Arm Height 24½" 4½" ENGLISH ARM		Arm Height 24½" 6½" ENGLISH ARM		Arm Height 26" 5" FAN ARM		Arm Height 26" 7" FAN ARM		Arm Height 25" 5" MODERN ARM		Arm Height 26½" 3½" SCROLL ARM		Arm Height 25½" 4½" SLOPE ARM		Arm Height 25½" 6½" SLOPE ARM	
	Width O/S	Width I/S	Width O/S	Width I/S	Width O/S	Width I/S	Width O/S	Width I/S	Width O/S	Width I/S	Width O/S	Width I/S	Width O/S	Width I/S	Width O/S	Width I/S
Chair	32	23	36	23	33	23	37	23	33	23	30	23	32	23	36	23
Ottoman	25	25	25	25	25	25	25	25	25	25	25	25	25	25	25	25
Loveseat	59	50	63	50	60	50	64	50	60	50	57	50	59	50	63	50
Mid-Size Sofa	69	60	73	60	70	60	74	60	70	60	67	60	69	60	73	60
Sofa	84	75	88	75	85	75	89	75	85	75	82	75	84	75	88	75
Armless Chair	25	25	25	25	25	25	25	25	25	25	25	25	25	25	25	25
Armless Loveseat	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50
Armless Sofa	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75
LAF Chaise	30	25	32	25	30	25	32	25	30	25	29	25	30	25	32	25
RAF Chaise	30	25	32	25	30	25	32	25	30	25	29	25	30	25	32	25
Chaise	34	25	38	25	35	25	39	25	35	25	32	25	34	25	38	25
LAF Ext Chaise	30	25	32	25	30	25	32	25	30	25	29	25	30	25	32	25
RAF Ext Chaise	30	25	32	25	30	25	32	25	30	25	29	25	30	25	32	25
Ext Chaise	34	25	38	25	35	25	39	25	35	25	32	25	34	25	38	25
37" LAF Crn Sofa	92	72	94	72	92	72	94	72	92	72	91	72	92	72	94	72
37" RAF Crn Sofa	92	72	94	72	92	72	94	72	92	72	91	72	92	72	94	72
40" LAF Crn Sofa	95	75	97	75	95	75	97	75	95	75	94	75	95	75	97	75
40" RAF Crn Sofa	95	75	97	75	95	75	97	75	95	75	94	75	95	75	97	75
42" LAF Crn Sofa	97	77	99	77	97	77	99	77	97	77	96	77	97	77	99	77
42" RAF Crn Sofa	97	77	99	77	97	77	99	77	97	77	96	77	97	77	99	77
LAF Chair	30	25	32	25	30	25	32	25	30	25	29	25	30	25	32	25
RAF Chair	30	25	32	25	30	25	32	25	30	25	29	25	30	25	32	25
LAF Loveseat	55	50	57	50	55	50	57	50	55	50	54	50	55	50	57	50
RAF Loveseat	55	50	57	50	55	50	57	50	55	50	54	50	55	50	57	50
LAF Sofa	80	75	82	75	80	75	82	75	80	75	79	75	80	75	82	75
RAF Sofa	80	75	82	75	80	75	82	75	80	75	79	75	80	75	82	75

	Arm Height 26" 5" SOCK ARM		Arm Height 26" 7" SOCK ARM		Arm Height 24½" 5" SQUARE ARM		Arm Height 24½" 7" SQUARE ARM		Arm Height 26" 3½" TRACK ARM		Arm Height 26" 5" TRACK ARM		Arm Height 26" 5" WING ARM	
	Width O/S	Width I/S	Width O/S	Width I/S	Width O/S	Width I/S	Width O/S	Width I/S	Width O/S	Width I/S	Width O/S	Width I/S	Width O/S	Width I/S
Chair	33	23	37	23	33	23	37	23	30	23	33	23	33	23
Ottoman	25	25	25	25	25	25	25	25	25	25	25	25	25	25
Loveseat	60	50	64	50	60	50	64	50	57	50	60	50	60	50
Mid-Size Sofa	70	60	74	60	70	60	74	60	67	60	70	60	70	60
Sofa	85	75	89	75	85	75	89	75	82	75	85	75	85	75
Armless Chair	25	25	25	25	25	25	25	25	25	25	25	25	25	25
Armless Loveseat	50	50	50	50	50	50	50	50	50	50	50	50	50	50
Armless Sofa	75	75	75	75	75	75	75	75	75	75	75	75	75	75
LAF Chaise	30	25	32	25	30	25	32	25	29	25	30	25	30	25
RAF Chaise	30	25	32	25	30	25	32	25	29	25	30	25	30	25
Chaise	35	25	39	25	35	25	39	25	32	25	35	25	35	25
LAF Ext Chaise	30	25	32	25	30	25	32	25	29	25	30	25	30	25
RAF Ext Chaise	30	25	32	25	30	25	32	25	29	25	30	25	30	25
Ext Chaise	35	25	39	25	35	25	39	25	32	25	35	25	35	25
37" LAF Crn Sofa	92	72	94	72	92	72	94	72	91	72	92	72	92	72
37" RAF Crn Sofa	92	72	94	72	92	72	94	72	91	72	92	72	92	72
40" LAF Crn Sofa	95	75	97	75	95	75	97	75	94	75	95	75	95	75
40" RAF Crn Sofa	95	75	97	75	95	75	97	75	94	75	95	75	95	75
42" LAF Crn Sofa	97	77	99	77	97	77	99	77	96	77	97	77	97	77
42" RAF Crn Sofa	97	77	99	77	97	77	99	77	96	77	97	77	97	77
LAF Chair	30	25	32	25	30	25	32	25	29	25	30	25	30	25
RAF Chair	30	25	32	25	30	25	32	25	29	25	30	25	30	25
LAF Loveseat	55	50	57	50	55	50	57	50	54	50	55	50	55	50
RAF Loveseat	55	50	57	50	55	50	57	50	54	50	55	50	55	50
LAF Sofa	80	75	82	75	80	75	82	75	79	75	80	75	80	75
RAF Sofa	80	75	82	75	80	75	82	75	79	75	80	75	80	75